



## Timer Instructions

**A:** Clear or Reset all data: Use a pen or pencil to gently depress the "R" button.

**B:** Select 12 hour or 24 hour time standard: Press the "MIN" and the "SEC" key at the same time.

**C:** Set the current time:

1. Set current day of week: Press the "CLOCK" and the "WEEK" keys at the same time. Continue until the current day displays.

2. Set current hour: Press the "CLOCK" and the "HOUR" keys at the same time. Continue until the current hour displays.

3. Set current minute: Press the "CLOCK" and the "MIN" keys at the same time. Continue until the current minute displays.

4. Set current second: Press the "CLOCK" and the "SEC" keys at the same time. Continue until the current second displays.

**D:** Set "On" and "Off" times for the appliance you will plug into the timer.

1. Press "PROG" key. "1 ON- :- -" will be displayed. You will now set the Start time. Press "WEEK" key. Continue until the desired Day or combination of Days is displayed.

Press "HOUR" key. Continue until the desired Hour is displayed.

Press "MIN" key. Continue until the desired Minute is displayed.

Press "SEC" key. Continue until the desired Second is displayed.

2. Press "PROG" key. "1 OFF- :- -" will be displayed. You will now set the End time.

Press "WEEK" key. Continue until the desired Day or combination of Days is displayed.

Press "HOUR" key. Continue until the desired Hour is displayed.

Press "MIN" key. Continue until the desired Minute is displayed.

Press "SEC" key. Continue until the desired Second is displayed.

If you wish to set multiple start/end times, repeat the instructions under "D" for "2 ON and 2 OFF", "3 On and 3 OFF", and so on. If you do not wish to set multiple start/end times, press the "CLOCK" key to return to the current time.

**E:** Press the "Finger" key to manually turn the appliance plugged into the timer "On" or "Off".

**NOTE:** The "On/Off" switch on the appliance itself must be in the "On" position for the following settings on the

timer to work correctly.

1: Press the "Finger" key. Continue until "ON" is displayed. Appliance plugged into the timer will remain "On" until the "Finger" key is manually pressed again.

2: Press the "Finger" key. Continue until "AUTO ON" is displayed. Appliance plugged into the timer will remain "On" until the next programmed "Off" time.

3: Press the "Finger" key. Continue until "OFF" is displayed. Appliance plugged into the timer will remain "Off" until the "Finger" key is manually pressed again.

4: Press the "Finger" key. Continue until "AUTO OFF" is displayed. Appliance plugged into the timer will remain "Off" until the next programmed "On" time.

When you have finished programming your timer, set to "AUTO On" if you want the appliance plugged into the timer to remain "On" until the next programmed "Off" time.

Likewise, set to "AUTO OFF" if you want the appliance plugged into the timer to remain "Off" until the next programmed "On" time.

**F:** Becomes random pattern. Press "WEEK" and "HOUR" key at the same time; Plus one hour. Press the "HOUR" and "MIN" key at the same time.